

## IndraControl XM

# Flexible control in real-time



## IndraControl XM Modular, robust and powerful

The family of the compact control platform IndraControl XM offers the latest hardware technology in a robust housing design. It combines the high real time capability of the Sercos automation bus and the flexibility of the I/O family IndraControl S20 to a modular and complete automation system for all applications in factory automation. The IndraControl XM22 control unit is also suitable for use in marine applications and explosive atmospheres.





#### Key technical data

- Protection class: IP20
- Onboard Sercos master with a minimum cycle time of 250 μs
- High control performance via Intel ATOM (600 MHz or 1,300 MHz)
- ► Gigabyte Ethernet, USB, SD card slot, diagnostics LED
- Modular expansion with extension and I/O modules
- Extended temperature range from -25 °C to +60 °C
- Certified solution based on IndraControl XM22 for marine applications and explosive atmospheres

#### Easy configuration, high-performance data processing

The IndraControl XM embedded control hardware is available for a variety of motion-logic applications. Local connection of the modules of the new IndraControl S20 I/O series expands the control system flexibly for high-performance process linkage. Decentralized I/Os, drives and additional system machinery are connected via Sercos as standard. Additional Ethernet protocols through optional extension modules extend the possibilities of integration. The servicefriendly and robust design reduces the maintenance and allows the use in many different applications.

#### Advantages resulting from special product features

- Easy and flexible system configuration with highperformance process data processing
- Skaled control system with modular and real-time capable I/O expansion
- Sercos as a universal automation bus for system-wide networking
- Maintenance-free through the waiving of wear parts such as fans and batteries
- Robust hardware design with regard to temperature, electromechanics, shock, vibration, EMC
- Simplified device handling through first touch web server
- The IndraMotion MLC scalable system firmware for motion logic applications

### Technical data

Processor         Miz         600 (Intel E60T)         1300 (Intel E660T)           CPU         MHz         600 (Intel E60T)         1300 (Intel E660T)           Memory         Task/application         MB         512         512           Hardware Interfaces         I x Ethernet (RJ45)         I x Ethernet (RJ45)         I x USB host         1 x USB host           USB         1 x USB host         I x USB device         1 x USB device         1 x USB device           Sto Card         1 x USB device         1 x USB cord slot         1 x USB device           10 extension         Connecting IndraControl S20 (/0 modules via bus socket modules XA-BS01 or XA-BS02         Connecting IndraControl S20 (/0 modules via bus socket modules XA-BS01 or XA-BS02           Functional extension         Connecting IndraControl S20 (/0 modules XA-BS01 or XA-BS02         Connecting IndraControl XM extension modules XA-BS01 or XA-BS02           Safety         Safetogica is IndraControl XM extension modules XA-BS01 or XA-BS02         Control to stocket module XA-BS01 or XA-BS02           Safety         Safetogica is IndraControl XM extension modules XA-BS01 or XA-BS02         Safetogica is IndraControl XM extension modules XA-BS01 or XA-BS02           Safety         Safetogica is IndraControl XM extension modules XA-BS01 or XA-BS02         Safetogica is IndraControl XM extension modules XA-BS01 or XA-BS02           Safety         Safetogica is IndraC			IndraControl XM21	IndraControl XM22
Memory         Image: Constraint of the second	Processor			
Memory         Image: start of the sta		MHz	600 (Intel E620T)	1300 (Intel E660T)
Task/application     MB     512     512       Hardware interfaces     I x Ethernet (RJ45)     1 x USB host     1 x USB host       USB     1 x USB device     1 x USB device     1 x USB device       SD card     1 x USD advice     1 x USB device     1 x USB device       I/O and functional extension     Connecting IndraControl 520 I/O modules with uso socket modules XAB-500 or XAB-502     Connecting IndraControl 520 I/O modules with uso socket modules XAB-501 or XAB-502       Functional extension     Connecting IndraControl XM extension modules XFED1 J.xxxx     Connecting IndraControl XM extension modules XFED1 J.xxx       Safety     Safetogic as IndraControl XM extension modules XFED1 J.xxx     Control KAB-502       Fieldbus (protocol)     Safetogic as IndraControl XM extension modules XFED1 J.SYNI     Safetogic as IndraControl XM extension modules XFED1 J.SYNI       FIORIPUS     Master on board     Master on abare with extension modules     Controller or device with extension modules       PROFINEUS     Master or adapter with extension modules     Scanner or adapter with extension modules     Scanner or adapter with extension modules       Raimum permissible voltage range     V DC     24     24       Maximum permissible voltage range     V DC     18 31.2 incl. tolerances       (U_m - U_m)     V DC     24     24       Marine certification     CE/UL/CSA     CE/UL/CSA       C	Memory			
Hardware interfaces         I x Ethernet (RJ45)         I x Ethernet (RJ45)           Effernet         1 x USB host         1 x USB host           USB         1 x USB device         1 x USB device           1 x USB device         1 x USB device         1 x USB device           Sto ard         1 x USB device         1 x USB device           IV O and functional extension         Connecting IndraControl S20 I/O modules values socket modules X45501 or X45502         Connecting IndraControl S20 I/O modules values socket modules X45501 r X45502           Functional extension         Connecting IndraControl S20 I/O modules values socket module X45502         Connecting IndraControl SM extension modules XFE01.1xxxx           Safety         SafeLogic as IndraControl XM extension module XFE01.1xxxx         extension modules XFE01.1xxxx           Safety         SafeLogic as IndraControl XM extension modules XFE01.1xxxx         extension modules XFE01.1xxxx           Safety         SafeLogic as IndraControl XM extension modules XFE01.1xxxx         extension modules XFE01.1xxxx           Safety         SafeLogic as IndraControl XM extension modules XFE01.1xxxx         extension modules XFE01.1xxxx           Safety         SafeLogic as IndraControl XM extension modules         SafeLogic as IndraControl XM extension modules           ForcHIBUS         Master or slave with extension modules         SafeLogic as IndraControl XM extension modules		MB	512	512
Ethernet       1 x Ethernet (RJ45)       1 x Ethernet (RJ45)         USB       1 x USB host       1 x USB host         SD card       1 x USB host       1 x USB device         SD card       1 x SD card slot       1 x SD card slot         I/O and functional extension       -       Connecting IndraControl S20 I/O modules via bus socket modules XFE01.1 xxxx       via bus socket modules XFE01.1 xxxx         Via control bus socket modules XFE01.1 xxxx       via bus socket modules XFE01.1 xxxx       via control bus socket modules XFE01.1 xxxx         Via control bus socket modules XFE01.1 xxxx       via control bus socket modules XFE01.1 xxxx       via control bus socket modules XFE01.1 xxxx         Safety       Safet.ogic as indraControl XM extension module XFE01.1 xxxx       via control bus socket modules XFE01.1 xxxx         Safets (protocol)       -       -       -         Fieldus (protocol)       -       -       -         Serros       Master on board       Master on slave with extension modules       Controller or device with extension modules         PROFIBUS       Master on slave with extension modules       Controller or device with extension modules       Controller or device with extension modules         CAN       2 x CAN master with extension modules       Controller or device with extension modules       Controller or device with extension modules         Ether				
USB     1 x USB host     1 x USB device     1 x USB device       SD card     1 x USB device     1 x USB device     1 x USB device       SD card slot     1 x SD card slot     1 x SD card slot       I/O and functional extension     Connecting IndraControl S20 I/O modules via bus socket modules XABS01 or XABS02     Connecting IndraControl S20 I/O modules via bus socket modules XABS01 or XABS02       Functional extension     Connecting IndraControl XM extension modules XED1.1.xxxx     Connecting IndraControl XM extension modules XED0.1.xxxx       Safety     SafeLogic as IndraControl XM extension module XED0.1.4XxX     Connecting IndraControl XM extension module XED0.1.4XxX       Fieldbus (protocol)     SafeLogic as IndraControl XM extension module XED0.1.4XxX     SafeLogic as IndraControl XM extension modules XED0.1.4XxX       PROFIBUS     Master or slave with extension modules     SafeLogic as IndraControl XM extension modules XED0.1.4XXX       PROFIBUS     Master or slave with extension modules     Scanner or adapter with extension modules       Supply voltage (U)     V DC     24     24       Mainum permissible voltage range (U_m - U_m)     V DC     18 31.2 incl. tolerances     18 31.2 incl. tolerances       (U_m - U_m)     V DC     18 31.2 incl. tolerances     18 31.2 incl. tolerances     XM2201       Marine certification - RIMA (Register) Italiano Navate)     C - 25 +60     - XM2201       Norke (Lopt Norske Veri			1 x Ethernet (BJ45)	1 x Ethernet (BJ45)
SD card     1 x USB device     1 x USB device       SD card dinctional extension     1 x SD card slot     1 x SD card slot       IO extension     Connecting IndraControl S20 I/O modules via bus socket modules XABS01 or XABS02     Connecting IndraControl XM extension modules XFE01.1xxxx     Connecting IndraControl XM extension modules XFE01.1xxxx       Safety     Safetogica sindraControl XM extension modules XFE01.1xxxx     Connecting IndraControl XM extension modules XFE01.1xxxx     Connecting IndraControl XM extension modules XFE01.1xxxx       Fledbus (protocal)     Safetogica sindraControl XM extension modules XFE01.1xxxx     Safetogica sindraControl XM extension modules       Fledbus (protocal)     Image: Safetogica SindraControl XM extension modules XFE01.1xxxx     Connecting IndraControl XM extension modules       Fledbus (protocal)     Image: Safetogica SindraControl XM extension modules     Connecting IndraControl XM extension modules       PROFINET RT Electrical Mata     Image: Safetogica SindraControl XM extension modules     Control Image: Safetogica SindraControl XM extension modules       CAN     2 x CAN master with extension modules     Scanner or adapter with extension modules     Scanner or adapter with extension modules       Canding error slaw extension sind safetogica SindraControl XM extension modules     Scanner or adapter with extension modules       Canding error slaw extension modules     Scanner or adapter with extension modules     Scanner or adapter with extension modules       Canding error slaw extension modules				
SD card       1 x SD card slot       1 x SD card slot         I/O and functional extension       Connecting IndraControl S20 I/O modules         Via bus socket modules XA-BS01 or XA-BS02       Via bus socket modules XA-BS02       Via bus socket modules XA-BS02         Functional extension       Connecting IndraControl XM       centersion modules XED11-xxxx         via control bus socket modules XA-BS02       via control bus socket modules XA-BS02       via control XM         Safety       SafeLogic as IndraControl XM extension modules XED11-xxxx       via control bus socket modules XA-BS02         Safety       SafeLogic as IndraControl XM extension modules XED11-SY01         Fledbus (protocol)       SafeLogic as IndraControl XM extension modules       Master on board         PROFIBUS       Master or slave with extension modules       Controller or device with extension modules         PROFIBUS       Scanner or adapter with extension modules       Scanner or adapter with extension modules         Cup_u - U_u_u)       VDC       18 31.2 incl. tolerances       18 31.2 incl. tolerances         Supply voltage (U)       VDC       14 31.2 incl. tolerances       18 31.2 incl. tolerances         VDC       18 31.2 incl. tolerances       18 31.2 incl. tolerances       18 31.2 incl. tolerances         VDC       18 31.2 incl. tolerances       18 31.2 incl. tolerances				
I/O and functional extension     Connecting IndraControl S20 I/O modules     Connecting IndraControl S20 I/O modules       IO extension     via bus socket modules XA-BS01 or XA-BS02     via bus socket modules XA-BS01 or XA-BS02       Functional extension     Connecting IndraControl XM     extension modules XFED1.1xxxx       via control bus socket modules XA-BS02     Connecting IndraControl XM     extension modules XFED1.1xxxx       via control bus socket module XA-BS02     SafeLogic as IndraControl XM extension     module XFED1.1xxxx       via control bus socket module XA-BS02     SafeLogic as IndraControl XM extension     module XFED1.1-SY-01       FleIdbus (protocol)     SafeLogic as IndraControl XM extension modules     SafeLogic as IndraControl XM extension modules       PROFIBUS     Master or board     Master or slave with extension modules       PROFIET RT     Controller or device with extension modules     Connecting IndraControl XM extension modules       Etertrical dat     Scanner or adapter with extension modules     Scanner or adapter with extension modules       Maximum permissible voltage range     V DC     18 31.2 incl. tolerances     18 31.2 incl. tolerances       (U <sub>an</sub> – U <sub>an</sub> )     V DC     18 31.2 incl. tolerances     18 31.2 incl. tolerances       Marine certification     CE/UL/CSA     CE/UL/CSA     Multication       Norms and standards     -     XM2201       Explosion protection	SD card			
IO       Connecting IndraControl S20 I/O modules wite bus socket modules XA-BS02       Connecting IndraControl S20 I/O modules wite sub socket modules XA-BS02         Functional extension       Connecting IndraControl XM extension modules XA-BS02       Connecting IndraControl XM extension modules XA-BS02         Safety       Safetogics as IndraControl XM extension modules XFE01.1xxxx via control bus socket module XA-BS02       Connecting IndraControl XM extension modules XFE01.1xxxx via control bus socket module XA-BS02         Safetogics as IndraControl XM extension modules XFE01.1:SY-01       Safetogics as IndraControl XM extension modules XFE01.1:SY-01         Flebbus (protocol)       Safetogics as IndraControl XM extension modules       Safetogics and IndraControl XM extension modules         Sercos       Master on slave with extension modules       Connecting IndraControl XM extension modules         PROFIBUS       Master on slave with extension modules       Connol XM extension modules         CAN       2 x CAN master with extension modules       Safetogics canner or adapter with extension modules         Electrical data       Supply voltage (U)       V DC       24       24         Maximum permissible voltage range       V DC       124       24         Marime certification       CE/UL/CSA       CE/UL/CSA       CE/UL/CSA         Norms and standards       -       -       XM2201         Certification       CE/UL/CSA				
Image: series of the series	•		Connecting IndraControl S201/O modules	Connecting IndraControl S20 1/0 modules
Functional extension         Connecting IndraControl XM extension modules XFE01.1-xx-xx via control bus socket modules XAFE02         Connecting IndraControl XM extension modules XFE02.1-xx-xx via control bus socket module XAFE02           Safet y         SafeLogic as IndraControl XM extension module XFE01.1-SY-01         SafeLogic as IndraControl XM extension module XFE01.1-SY-01           Fieldbus (protocol)         Master on board         Master on board         Master on board           PROFIBUS         Master on slave with extension modules         Master or slave with extension modules           PROFINET RT         Controller or device with extension modules         Controller or device with extension modules           EtherNet/IP         Scanner or adapter with extension modules         Sarener or adapter with extension modules           Electrical dat         2 x CAN master with extension modules         2 x CAN master with extension modules           Supply voltage (U)         V DC         24         24           Maximum permissible voltage range (Um_m - Um_m)         V DC         18 31.2 incl. tolerances         18 31.2 incl. tolerances           VDC         VDC         24         24         24           Maximum permissible voltage range (V DC         2 (E/UL/CSA         CE/UL/CSA           Arrise cortification         Scance or device with extension modules         3				
extension modules XFE01.1-xx:xxextension modules XFE01.1-xx:xxVia control bus socket module XA-BS02via control bus socket module XA-BS02SafetySafetogicas IndraControl XM extension module XFE01.1-SY-01Safetogicas IndraControl XM extension module XFE01.1-SY-01Fieldbus (protocol)Master on boardMaster on boardPROFIBUSMaster or slave with extension modulesMaster or slave with extension modulesPROFIDUSController or device with extension modulesController or device with extension modulesPROFIDUS2 controller or device with extension modulesScanner or adapter with extension modulesCAN2 x CAN master with extension modules2 controller or device with extension modulesElectrical dat2 x CAN master with extension modules8 31.2 incl. tolerancesCum_ on_maxiVDC14 31.2 incl. tolerances18 31.2 incl. tolerancesCufficationCE/UL/CSACE/UL/CSAMarine certificationCE/UL/CSACE/UL/CSAMarine certification </td <td>Functional extension</td> <td></td> <td></td> <td></td>	Functional extension			
SafeLy     SafeLogic as IndraControl XM extension module XFE01-1-SY-01     SafeLogic as IndraControl XM extension module XFE01-1-SY-01       Fieldbus (protocol)     Sercos     Master on board     Master on board       PROFIBUS     Master on slave with extension modules     Master or slave with extension modules       PROFIBUS     Master or slave with extension modules     Controller or device with extension modules       PROFINET RT     Controller or device with extension modules     Scanner or adapter with extension modules       CAN     2 x CAN master with extension modules     Scanner or adapter with extension modules       Supply voltage (U)     V DC     24     24       Maximum permissible voltage range (U <sub>ma</sub> )     V DC     24     24       Marine certification     CE/UL/CSA     CE/UL/CSA       Certification     CE/UL/CSA     CE/UL/CSA       Marine certification     CE/UL/CSA     CE/UL/CSA       V DC     CE/UL/CSA     CE/UL/CSA       Marine certification     CE/UL/CSA     CE/UL/CSA       V DC     CE/UL/CSA     CE/UL/CSA       Maxine vertification     CE/UL/CSA     CE/UL/CSA       V DC     CE/UL/CSA     CE/UL/CSA       Marine certification     CE/UL/CSA     CE/UL/CSA       V DC     CE/UL/CSA     CE/UL/CSA       Certification     CE/UL/CSA <td< td=""><td></td><td></td><td></td><td>C C</td></td<>				C C
Image: module XFE01-1SY01         module XFE01-1SY01           Fieldsus (protect)         Fieldsus (protect)           Sercos         Master on board         Master on board           PROFIBUS         Master on slave with extension modules         Master or slave with extension modules           PROFIDUS         Image: Controller or device with extension modules         Controller or device with extension modules           EtherNet/IP         Image: Controller or device with extension modules         Scanner or adapter with extension modules           EtherNet/IP         Image: Controller or device with extension modules         Scanner or adapter with extension modules           EtherNet/IP         Image: Controller or device with extension modules         Scanner or adapter with extension modules           EtherNet/IP         Image: Controller or device with extension modules         Scanner or adapter with extension modules           EtherNet/IP         Image: Controller or device with extension modules         Scanner or adapter with extension modules           EtherNet/IP         Vito         2 x CAN master with extension modules         Scanner or adapter with extension modules           EtherNet/IP         Vito         2 4         Adapter or shave with extension modules           EtherNet/IP         Vito         1 8 31.2 incl. tolerances         Is a			via control bus socket module XA-BS02	via control bus socket module XA-BS02
Fieldbus (protocol)       Master on board       Master on board         Sercos       Master on slave with extension modules       Master or slave with extension modules         PROFINET RT       Controller or device with extension modules       Controller or device with extension modules         EtherNet/IP       Scanner or adapter with extension modules       Scanner or adapter with extension modules         CAN       2 x CAN master with extension modules       Scanner or adapter with extension modules         Electrical data       2 x CAN master with extension modules       2 x CAN master with extension modules         Supply voltage (U)       V DC       24       24         Maximum permissible voltage range (U <sub>mm</sub> - U <sub>mm</sub> )       V DC       18 31.2 incl. tolerances       18 31.2 incl. tolerances         Norms and standards       -       -       XM2201       -         Certification       CE/UL/CSA       CE/UL/CSA       XM2201         ABS (American Bureau of Shipping)       -       -       -       XM2201         > BSH (Federal Maritime and Hydro- geraphic Agency of Germany)       -       -       -       -         > Explosion protection       -       -       -       -       -         Explosion protection       %       5 95 (EN 61131-2)       5 95 (EN 61131-2) <td< td=""><td>Safety</td><td></td><td>SafeLogic as IndraControl XM extension</td><td>SafeLogic as IndraControl XM extension</td></td<>	Safety		SafeLogic as IndraControl XM extension	SafeLogic as IndraControl XM extension
SercosMaster on boardMaster on boardPROFIBUSMaster or slave with extension modulesMaster or slave with extension modulesPROFINET RTController or device with extension modulesController or device with extension modulesEtherNet/IPScanner or adapter with extension modulesScanner or adapter with extension modulesCAN2 x CAN master with extension modulesScanner or adapter with extension modulesElectrical data2 x CAN master with extension modulesSupply voltage (U)V DC2424Maximum permissible voltage range (Umin - Umin)V DC18 31.2 incl. tolerancesNorms and standardsCE/UL/CSACertificationCE/UL/CSACE/UL/CSAMarine certificationCE/UL/CSAAdamine certification- ABS (American Bureau of Shipping) - BSH (Federal Maritime and Hydro- graphic Agency of Germany) - EN (Lioqu's Register) RUA (Registro Italiano Navate)Explosion protection (ECE) RINA (Registro Italiano Navate)*C-25 +60- Rubel bundity (operation)*C-25 +60- Rubel bundity (operation)*C-95 (EIN 61131-2)- Protection class[P20IP20LoadIP20IP20			module XFE01-1-SY-01	module XFE01-1-SY-01
PROFIBUSMaster or slave with extension modulesMaster or slave with extension modulesPROFINET RTController or device with extension modulesController or device with extension modulesEtherNet/IPScanner or adapter with extension modulesScanner or adapter with extension modulesZAN2 x CAN master with extension modulesScanner or adapter with extension modulesEtherNet/IPVDC2424Maximum permissible voltage rangeVDC18 31.2 incl. tolerances18 31.2 incl. tolerancesNorms and standardsCE/UL/CSACE/UL/CSACE/UL/CSAMarine certificationCE/UL/CSACE/UL/CSAABS (Hederal Maritime and Hydro- graphic Agercy of Germany)SV (Bureau Veritas)DNV-GL (Det Norske Veritas) erstnot retainen value)RINA (Registro Italiano Navate)C25 +6025 +60Explosion protection IECEX°CAllowable humidity (operation)%5 +60-NoteIP20IP20IP20LotadIP20IP20IP20LotadIP20IP20IP20LotadIP20IP20IP20LotadIP20IP20IP20LotadIP20IP20IP20LotadIP20IP20IP20LotadIP20IP20IP20LotadIP20IP20IP20LotadIP20IP20IP20LotadIP20	Fieldbus (protocol)			
PROFINET RTController or device with extension modulesController or device with extension modulesEtherNet/IPScanner or adapter with extension modulesScanner or adapter with extension modulesCAN2 x CAN master with extension modules2 x CAN master with extension modulesElectrical dataVDC2424Maximum permissible voltage range (Umm - Umme)VDC18 31.2 incl. tolerances18 31.2 incl. tolerancesNorns and standardsCer/UL/CSACE/UL/CSACE/UL/CSACertificationCE/UL/CSACE/UL/CSAMarine certificationCE/UL/CSACE/UL/CSAAdsine certification-Scanner or device with extension woule- ABS (American Bureau of Shipping)-SSScanner of Germany)- BSH (Federal Maritime and Hydro- graphic Agency of Germany)XM2201- BSH (Federal Maritime and Hydro- graphic Agency of Germany)XM2201- RINA (Registro Italiano Navate)XM2201- RINA (Registro Italiano Navate)Scanner or 400- RINA (Registro Italiano Navate)Allowable temperature (operation)%5 95 (EN 61131-2)5 95 (EN 61131-2)- Protection classIP20IP20IP20IP20LoadVibration resistanceg5 95 (EN 61131-2)5 95 (EN 61131-2)	Sercos		Master on board	Master on board
EtherNet/IPScanner or adapter with extension modulesScanner or adapter with extension modulesCAN2 x CAN master with extension modules2 x CAN master with extension modulesElectrical data2 x CAN master with extension modules2 x CAN master with extension modulesSupply voltage (U)V DC2424Maximum permissible voltage range (Umm - Ummx)VDC18 31.2 incl. tolerances18 31.2 incl. tolerancesNorms and standardsCE/UL/CSACE/UL/CSACE/UL/CSACertificationCE/UL/CSACE/UL/CSAMarine certification	PROFIBUS		Master or slave with extension modules	Master or slave with extension modules
CAN2 x CAN master with extension modules2 x CAN master with extension modulesElectrical dataSupply voltage (U)V DC2424Maximum permissible voltage range (Umin - Umix)V DC18 31.2 incl. tolerances18 31.2 incl. tolerancesNorms and standardsCE/UL/CSACE/UL/CSACertificationCE/UL/CSACE/UL/CSAMarine certification - - ABS (American Bureau of Shipping) - BSH (Federal Martime and Hydro- graphic Agency of Germany) - BW (Bureau Veritas)-DW-SGL (Det Norske Veritas I Germanischer Lloyd) - LR (Lloyd's Register) - RINA (Registro Italiano Navate)-Explosion protection IECEXAmbient conditionsAllowable temperature (operation) Mobale humidity (operation)%5 95 (EN 61131-2)Protection classIP20IP20LoadIP20IP20	PROFINET RT		Controller or device with extension modules	Controller or device with extension modules
Electrical dataSupply voltage (U)V DC2424Maximum permissible voltage range (U <sub>min</sub> - U <sub>max</sub> )V DC18 31.2 incl. tolerances18 31.2 incl. tolerancesNorms and standardsCertificationCE/UL/CSACE/UL/CSAMarine certification- ABS (American Bureau of Shipping) - BSH (Federal Maritime and Hydro- graphic Agency of Germany) - BV (Bureau Veritas)	EtherNet/IP		Scanner or adapter with extension modules	Scanner or adapter with extension modules
Supply voltage (U)V DC2424Maximum pernissible voltage range (Umin - Umax)V DC18 31.2 incl. tolerances18 31.2 incl. tolerancesNorms and standardsCertificationCE/UL/CSACE/UL/CSAMarine certificationCE/UL/CSACE/UL/CSAMarine certification	CAN		2 x CAN master with extension modules	2 x CAN master with extension modules
Maximum permissible voltage range (Umin - Uma)V DC18 31.2 incl. tolerances18 31.2 incl. tolerancesNorms and standardsCertificationCE/UL/CSACE/UL/CSACertificationCE/UL/CSACE/UL/CSAMarine certificationCE/UL/CSACE/UL/CSAMarine certificationCE/UL/CSACE/UL/CSAABS (American Bureau of Shipping) BSH (Federal Maritime and Hydro- graphic Agency of Germany)SBY (Federal Maritime and Hydro- graphic Agency of Germany)BSV (Federal Maritime and Hydro- graphic Agency of Germany)BSV (Federal Maritime and Hydro- graphic Agency of Germany)SW (Bureau Veritas) Germanischer Lloyd)XM2201Lic (Loyd's Register) Schinder Lloyd)XM2201Lic (Loyd's Register) RINA (Registro Italiano Navate)Explosion protection IECExAllowable temperature (operation)°C-25 +60-25 +60Allowable humidity (operation)%5 95 (EN 61131-2)5 95 (EN 61131-2)Protection classIP20IP20IP20LoadVibration resistanceg5-5	Electrical data			
(U_min - U_max)Image: Constraint of the second	Supply voltage (U)	V DC	24	24
Norms and standardsCertificationCE/UL/CSACE/UL/CSAMarine certification - ABS (American Bureau of Shipping) - BSH (Federal Maritime and Hydro- graphic Agency of Germany) - BSH (Federal Maritime and Hydro- graphic Agency of Germany) - BV (Bureau Veritas) - DNV-GL (Det Norske Veritas   Germanischer Lloyd) - LR (Lloyd's Register) 	Maximum permissible voltage range	V DC	18 31.2 incl. tolerances	18 31.2 incl. tolerances
CertificationCE/UL/CSACE/UL/CSAMarine certification - ABS (American Bureau of Shipping) - BSH (Federal Maritime and Hydro- graphic Agency of Germany) - BV (Bureau Veritas) - Germanischer Lloyd) - LR (Lloyd's Register) - RINA (Registro Italiano Navate)XM2201Explosion protection IECExXM2201Ambient conditionsXM2201Ambient conditionsAllowable humidity (operation)%5 95 (EN 61131-2)5 95 (EN 61131-2)Protection class-IP20IP20Urbation resistanceg5 955	$(U_{min} - U_{max})$			
Marine certification - ABS (American Bureau of Shipping) - BSH (Federal Maritime and Hydro- graphic Agency of Germany) - BV (Bureau Veritas) - DNV-GL (Det Norske Veritas ] Germanischer Lloyd) - LR (Lloyd's Register) - RINA (Registro Italiano Navate) RINA (Registro Italiano Navate) Rubid Conditions Ambient conditions-Anlowable temperature (operation) Protection class°C- 25 + 60 102 October 102 O	Norms and standards			
- ABS (American Bureau of Shipping) - BSH (Federal Maritime and Hydro- graphic Agency of Germany) - BV (Bureau Veritas) - DNV-GL (Det Norske Veritas   Germanischer Lloyd) - LR (Lloyd's Register) - RINA (Registro Italiano Navate)	Certification		CE/UL/CSA	CE/UL/CSA
IECExImage: Constraint of the second sec	<ul> <li>ABS (American Bureau of Shipping)</li> <li>BSH (Federal Maritime and Hydrographic Agency of Germany)</li> <li>BV (Bureau Veritas)</li> <li>DNV-GL (Det Norske Veritas   Germanischer Lloyd)</li> <li>LR (Lloyd's Register)</li> </ul>		-	XM2201
Allowable temperature (operation)       °C       -25 +60       -25 +60         Allowable humidity (operation)       %       5 95 (EN 61131-2)       5 95 (EN 61131-2)         Protection class       IP20       IP20       IP20         Load       Vibration resistance       g       5       5			-	XM2201
Allowable humidity (operation)%5 95 (EN 61131-2)5 95 (EN 61131-2)Protection classIP20IP20LoadVibration resistanceg5Solution classg5Solution	Ambient conditions			
Protection class     IP20     IP20       Load     g     5	Allowable temperature (operation)	°C	-25 +60	-25 +60
Load     g     5       Vibration resistance     g     5	Allowable humidity (operation)	%	5 95 (EN 61131-2)	5 95 (EN 61131-2)
Vibration resistance g 5 5	Protection class		IP20	IP20
	Load			
Shock resistance g 30 30	Vibration resistance	g	5	5
	Shock resistance	g	30	30



Bosch Rexroth AG Bgm.-Dr.-Nebel-Str. 2 97816 Lohr, Germany www.boschrexroth.com

Find your local contact person here:

www.boschrexroth.com/contact

#### **Further information:**

www.boschrexroth.com/indracontrol-xm









248-373-1600 • morrell-group.com • orders@morrellinc.com MI • IN • IL • OH • ON, CAN



The data specified above only serve to describe the product. No statements concerning a certain condition or suitability for a certain application can be derived from our information. The information given does not release the user from the obligation of own judgment and verification. It must be remembered that our products are subject to a natural process of wear and aging.

R999000426 (2017-06) © Bosch Rexroth AG 2017 Subject to revisions!